


市區分校 Town Centre

自動化教學控制台操作指引

Instruction of Automatic Teaching Console



步驟如下所述：

The Procedure is as follows:

- 按 **AV SYSTEM ON** 鍵開啓系統電源，並從**訊號選擇鍵**中選按所需的器材。(例如：用電腦，請按 **PC** 鍵。)
(註：手提電腦需要訊號線連接到教育控制台。)
Press **AV SYSTEM ON** button to switch on system power. Select the equipment you want and press the corresponding button in **SOURCE SELECTION**. (eg: Press **PC** button if you want to use the computer.)
(Remarks: Notebook needs to connect VGA port on teaching console by VGA cable.)
- 大約 20 秒後，影音訊號便會投射在銀幕上。
AV signal will appear on the screen around 20 seconds later.
- 若需要播放、暫停、停止、向前捲帶、向後捲帶、向前快鏡或向後快鏡，請按 **訊號控制鍵** 控制有關器材。
Use **SOURCE CONTROL** buttons such as Play, Pause, Stop, F-forward, Reverse and Skip +/- on Control Panel to control related equipment.
- 當使用完教學控制台或離開課室，請按 **AV SYSTEM OFF** 鍵，教學控制台系統會自動關掉所有影音及多媒體裝置。
When finish using the AV equipment or when class finishes, please press **AV SYSTEM OFF** button. Then, the AV equipment will be automatically turned off.
- 當按 **AV SYSTEM OFF** 鍵後，請給與影音／電腦投射器 20 秒冷卻時間後，才可以按訊號選擇鍵，重新啓動影音及多媒體裝置。
After pressing **AV SYSTEM OFF** button, please wait for 20 seconds before restarting the system

* 若需要課室技術支援，請致電內線 8581 或到 308 室（資訊科技及服務處）尋求協助。

* Should you need any technical support, please call ext.8581 or go to Room 308 (Office of Information Technology & Service).